

Drying Cabinet

Model: D0012

a measurable difference...

IDM[®]
instruments

The Drying Cabinet is used for the rapid drying of textile samples.

The cabinet is fitted with three rows of folding pull-out hangers, corresponding to a total of 16 metres of clothesline to support the samples on. The Drying Cabinet can be operated at different temperatures, ranging from Normal, Medium or Air Fluff temperature.

Applications:

- Drying of Textile Samples

Features:

- Racks equivalent to 16m
- Racks also fitted inside of door
- Dehumidification capacity: 14 g/min
- Airing capacity: 180 m³/h

Benefits:

- The Drying Cabinet has multiple temperature ranges allowing you to simulate both “normal” drying regimes or rapidly dry items for maximum test efficiency
- Our clever system racking creates 16 meters of effective drying space, so you can dry more items in this small footprint cabinet
- 8 preset timers offering “set and forget” ease of use

Standards:

- N/A

Options:

- Stainless Steel Construction

Connections:

- **Energy consumption:** Normal 0.9 kWh/kg
- **Electrical:** 220/240 VAC @ 50 HZ or
110 VAC @ 60 HZ
(please specify when ordering)

Dimensions:

- **H:** 1,730 mm
- **W:** 595 mm
- **D:** 640 mm
- **Weight:** 60 kg

