

Reel Hardness Probe

Model: R0014

a measurable difference...

IDM[®]
instruments

The Reel Hardness Probe has been specially designed as a hand held instrument is used for measuring the tightness of paper rolls after rewind.

Basic function includes setting the tip of the probe into a paper roll and applying force until the spring gives way, determine a result on the probe scale.

Applications:

- Paper

Features:

- Stainless Steel Probe
- Aluminium Holder

Benefits:

- Easy to use
- Fast results
- Accurate

Standards:

N/A

Dimensions:

- **H:** 230mm
- **W:** 25mm
- **D:** 25mm
- **Weight:** 285g

